



JP1

L-1	1
油室故障RL1-COM	2
油室故障RL1-NO	3
加热RL-COM	4
加热RL-NO	5
绕组故障RL1-COM	6
绕组故障RL1-NO	7
绕组	8
	9
	10
	11
	12
	13
	14
	15
	16
	17
	18
	19
	20
	接口

加热 停泵1
停泵2

Title		
NS-2BQ-face		
Size	Number	Revision
A4	2/2	
Date:	9-Oct-2010	Sheet of
File:	D:\产品\产品NS\产品NS-2(大)V6SCH\NS2BQ.DDB	1 of 1